




STEP 1




STEP 2






STEP 3



STEP 4



STEP 5

STEP 6

STEP 7


LISTA VITI SCREWS LIST		
N°	DESCRIZIONE DESCRIPTION	Q.t
1	Vite senza testa estremo conico M12 x L20 Socket set screw cone point M12 x L20	2
2	Vite senza testa estremo piano M12 x L20 Socket set screw flat point M12 x L20	3
3	Vite esagonale flangiata M6 x L16 Hexagonal screw M6 x L16	10
4	Rondella M6 x D24 Washer M6 x D24	8
5	Dado esagonale flangiato M6 Hexagonal nut M6	8
6	Vite esagonale flangiata M8 x L20 Hexagonal screw M8 x L20	4
7	Dado esagonale flangiato M8 Hexagonal nut M8	4
8	Vite testa a croce M2.9 x L12 Cross head screw M2.9 x L12	2

Western Co.
Via Pasubio n°1
63074, San Benedetto del Tronto (AP), Italy.
Tel. 0735 751248, Fax. 0735 751254
e-mail info@western.it, Web www.western.it